








980053

MONTAGEANLEITUNG
ASSEMBLY INSTRUCTIONS
MONTAGE AANWIJZING
INSTRUCTIONS DE MONTAGE
NÁVOD K MONTÁŽI







KUNSTSTOFF-LL











980053

07.04.00 / 20.07.07 07 07


1/7

 111 102 3 x 15 mm	A 4 x
 V1	4 x
 LL1 4 117231 3,5 x 15 mm	2 x
 G63 G1 121 370	12 x


 111 103	C 4 x
 353 018 $\phi 8 \times 30$	D 8 x
 111 609	B 4 x
 163 007	Z 1 x



385x345x15




385x345x15




520x379x18




⑧ 487x85x15




⑨ 487x64x15





496x341x2,5




466x315x2,5

















513x164x15







316/481/316x75x12,5









5



111 103


353 018 $\phi 8 \times 30$

6





111 609

B 3 x 15 mm



V1




980053

07.04.00 / 20.07.07




07 07

5/7




7



8








9




5,5 x 10 mm

G63



Anzahl
Aantal
A lot of
Quantite


$$\begin{pmatrix} \wedge \\ \times \\ 4 \\ \vee \end{pmatrix}$$

15

121 370\

980053

07.04.00 / 20.07.07

07 07

7/7